



## Power Wash


hold down keys in this order  
**Esc+Refresh+Power**




The + is not pressed, Refresh is the 4th key from the left at the top of the keyboard  
once it restarts it will be at a screen with a yellow ! (DELL)



(HP)




hold down keys in this order  
**Ctrl+Alt+d**



next press **enter**

on the next screen **press space** bar then enter



once the Chromebook boots up you will need to choose your wireless network  
at the login screen you should see in the username field **@students.mpsd.org**  
if you do your good to go, **if not**  
hold down keys in this order  
**Ctrl+Alt+E**  
this will bring you to the enrollment screen  
just type your full email address and password, this will enroll the Chromebook  
after that you should be all set